

QT636

Quantec Interface Unit c/w Remote Socket



Overview

Allows any device with a normally open or normally closed 6.35mm (1/4 inch) jack plug to be connected to Quantec.

Particularly suited for use with our NC805MD Portable Movement Detector (n/ooperation), QT644 Floor Pressure mat (n/ooperation), QT633 Bed Exit mat (n/coperation) or QT634 Chair ExitMat (n/c operation).

Must be wired as a slave to a QT602 or QT609 range addressable call point or QT630 dementia care controller.

When thedevice connected to the QT636 is operated a call will be generated on the Quantec call system as programmed.

Mounts on a standard UK 25mm single gang back box.

Technical Specifications

Quiescent current	1mA.
Alarm current	1mA.
Connections	N-; N+; L+; SW. Wired as a slave to a QT602 call point, QT609 call point or QT630 dementia care controller.
Onboard 6.35mm Remote Jack Socket	Yes, can be configured to accept a n/o or n/c jack plug.



T 01942 322744 **F** 01942 829867 E sales@c-tec.co.uk



















Onboard Sounder	No.
Onboard Infrared Receiver	No.
Product dimensions (mm)	87~W~x~87~H~x~33~D~mm. Can be mounted on a standard UK 25mm single gang flush or surface back box.
Construction & finish	Plastic.
IP Rating	IP20.
Weight	68g
Operating conditions/temperature	-5°C to +40°C. Max relative humidity: 95%.



































